



VTech CS6114 Battery Replacement

A step-by-step guide to replace the battery for a VTech CS6114 cordless phone.

Written By: Sheckeem Daley



INTRODUCTION

The compatible battery available on the official VTech website for the CS6114 cordless phone costs the same as a new CS6114 phone.



PARTS:

- [VTech CS6114 Compatible Battery](#) (1)
-

Step 1 — Battery



- Hold handset with one hand with the keypad facing downward.

Step 2



- Place thumb on the indentation located at the top of the battery cover.
- Press down and gently slide the cover off the back of the handset.
- Set the battery cover aside.

Step 3



- Use thumb and index finger to gently pull the wired connection from the handset.
- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 12:45:35 PM.